

polkaudio®

the speaker specialists®

620-RT

**Mounting Template and Instructions
Gabarit D'Installation et Consignes**

8 3/16 in.

**Follow these steps while installing the 620-RT
Étapes à suivre pour installer le 620-RT**

- 1) Determine speaker location. Be sure that it does not interfere with studs/joists.
- 2) Hold or tape the template to the mounting location.
- 3) Trace along the outside of the template.
- 4) Carefully cut a hole ensuring that it is no larger than the shape you traced.
- 5) Attach the speaker wires to the terminals on the back of the speaker. Use RED for the positive (+) wire and BLACK for the negative (-) wire.
- 6) Position the speaker and tighten the six screws until snug. **CAUTION: DO NOT OVER-TIGHTEN SCREWS!**
- 7) Install grille.

- 1) Déterminez l'emplacement. Assurez le dégagement adéquat des montants/solives.
- 2) Tenez ou fixez le gabarit sur l'emplacement déterminé.
- 3) Tracez le pourtour du gabarit.
- 4) Taillez l'embrasure. Assurez-vous qu'elle n'est pas plus grande que le tracé.
- 5) Connectez les câbles de h.p. aux bornes situées à l'arrière du haut-parleur. ROUGE = fil positif (+) / NOIR = fil négatif (-).
- 6) Installer le haut-parleur et serrez fermement les six vis. **ATTENTION: NE SERREZ PAS TROP LES VIS!**
- 7) Installez la grille.



**AVAILABLE AT
DIGITAL CINEMA**

HBP2138A